Liverpool Adventure Outfitters Giant Expression E+ E-Bike Quick Start Guide

Welcome! Thank you for choosing Liverpool Adventure Outfitters. The Giant Expression E+ is designed to make your ride easier, more comfortable, and more enjoyable. Follow these simple steps before heading out.

TURNING THE BIKE ON
Press and hold the Power button on the handlebar control.
The display will turn on and show the battery level.
You're ready to ride!

CHOOSING YOUR LEVEL ASSIST

Use the + (up) and – (down) buttons on the controller to select your preferred assistance.

1st Level-Eco – Maximum battery range with light assistance.

2nd Level-Basic – Comfortable cruising on flat terrain.

3rd Level-Active – Great for everyday riding.

4th Level-Sport – Extra help for hills and headwinds.

5th Level-Power – Maximum assistance for steep climbs.

Once you've selected one of these modes, **Auto-Smart Assist is turned off** and the motor will provide the fixed level of assistance you selected.

Auto-Smart Assist – Automatically adjusts the motor to match your riding effort. We recommend not to use Auto-Smart Assist to minimize battery consumption.

If you want no motor assistance at all continue pressing the – button until you reach off, or turn the e-bike off by pressing and holding the power button.

HOW THE EBIKE WORKS
The motor only assists while you are pedaling.
Stop pedaling or apply the brakes and the motor assistance stops.
Shift gears just like a regular bicycle for the smoothest ride.

RIDING TIPS
Start with no assistance until you feel in control and comfortable.
Shift into lower gears before climbing hills.
Brake early and use both brakes evenly.
Ride at a comfortable speed and stay aware of pedestrians and traffic.

BATTERY TIPS
Average riding range: 55–170 km depending on terrain, rider weight, wind, and assist level. Using lower assist levels will increase your range

Before returning your bike, please:
Remove any personal belongings.
Report any damage or mechanical issues.
Please return all equipment with the bike.

Have Questions?
Our team is happy to help before, during, or after your ride. Liverpool Adventure Outfitters by phone 902 354 2702 or email tours@liverpooladventureoutfitters.com
Have an amazing ride and explore safely!